



Notes:

Omit C1, MIDI IN pin 2 to gnd and U2 pin 2 to +5v connections for external power. Use only regulated +5v external supply

S1 open = midi to din
 S1 closed = din to midi

**MIDI To Din / Din To MIDI
 Sync Convertor v1.1**

C Fraser, 22/12/2005